

OPA or Glutaraldehyde Minor Spill (Less than 1 Gallon) Clean Up Procedures

Only trained staff may clean up a minor spill.

- 1. **Notify co-workers** of spill and **restrict access** to affected area during clean up.
- 2. **Retrieve OPA/Glutaraldehyde Spill Kit** (Civco 610-1098, formerly PCI Medical AC-SP1) that contains Glute-Out neutralizer, personal protective equipment and absorbent pads. Check expiration date of Glute-Out and don't use if expired.
- 3. Wear **personal protective equipment**: hair covering, chemical splash goggles, gown, nitrile gloves, and shoe covers.
- Sprinkle Glute-Out liberally over the spill (following instructions on Glute-Out bottle). Wait about 5 minutes for neutralization, occurring when solution changes color: Yellow Orange to Green Brown (OPA) Yellow Orange to Red Orange (glutaraldehyde)
- 5. Place **absorbent pads** over the spill. Use pads to pick up spilled material.
- 6. Place waste material in a waste disposal bag and dispose of it in regular trash. Keep goggles for reuse if possible.
- 7. Notify EH&S (4-6783) about spill: location, date, quantity spilled, and cause of spill.
- 8. **Reorder replacement spill kit** through Lawson (#41899).
- 9. **Replace** expired Glute-Out by ordering through Lawson
 - Large bottle NG-5GAL Lawson# 41898
 - Small bottle NG-1GAL Lawson# 41859





Glute-Out is a glycine-based powder neutralizer that deactivates OPA and glutaraldehyde.

For a major spill or if you need assistance: In University Hospital: Call University Police, 911

(cell phone: 631-632-3333)

In Hospital Off Site Facilities: Call local police, 911